

2010 Change Location Modification



I removed the coin holder.



I filled it with JB Weld



After 48 hours I cut a hole in it using a hole saw and drill press.



I tested the fit with a USB and 3.5mm extension cable.



I realized that there was too much plastic and the threaded area was too small to accommodate the plastic nut.



I cut the excess plastic off. Then I sanded it down. I found that it was not completely straight so I added more JB Weld and sanded it down.





When I was done, I painted it black.



Here is the final product.



All total it took me about three days.