

VEHICLE WIRING CHART

(All wire color information is for reference only and may vary by vehicle)

Please verify with a test light

MAKE	MODEL	YEARS	WIRE COLOR		WIRE LOCATION (*Note 1)
			LOCK	UNLOCK	
Chevy/GMC	Silverado/Sierra	99-02	Tan	Gray	Driver Side Kick Panel Or Just Below Driver Side Fuse Block
Chevy/GMC	Silverado/Sierra S-10/Sonoma Colorado/Canyon	03-06	Tan	Gray	Driver Side Door Between Switch and Lock Actuator (*Note 2)
Chevy/GMC	Silverado/Sierra S-10/Sonoma Colorado/Canyon	07+	Tan	Blue	Driver Side Door Between Switch and Lock Actuator (*Note 2)
Chevy/GMC Crew Cab	Silverado/Sierra S-10/Sonoma Colorado/Canyon	03+	Tan	Gray	Under the sill plate in the wiring harness that goes under the driver's side seat.
Chevy/GMC	Full Size	88-98	Tan	Gray	Driver Side Kick Panel
Chevy/GMC	S-10	94-02	Tan	Gray	Driver Side Kick Panel
Ford	Sport Trac	01-06	Pink	Pink/Black	Passenger Kick Panel (*Note 5)
Ford	Sport Trac	07+	Gray/Brown	Purple/Gray	Passenger Kick Panel (*Note 5)
Ford	F-150 / F-250 / F-350	97-03	Red/Green	Pink/Orange or Red/Orange	Above Steering Column or Driver Side Kick Panel (*Note 5)
Ford	F-150 / F-250 / F-350	04-07	Pink/Black	Pink/Orange or Red/Orange	Above Steering Column or Drivers Side Kick Panel (*Note 5)
Ford	F-150/F-250/F-350	08	Gray or Gray/Tan	Purple or Purple/Gray	Above Steering Column or Drivers Side Kick Panel (*Note 5)
Ford	F-150/F-250/F-350	09+	Gray/Black	Lt. Blue/Lt Green	Above Steering Column or Drivers Side Kick Panel (*Note 5)
Ford	Ranger	99-07	Pink/Black	Pink/Orange	Passenger Side Kick Panel (*Note 5)
Ford	Ranger	08+	Blue/Green or White/Purple	Gray/Black or Gray/Purple	Passenger Side Kick Panel (*Note 5)
Dodge	Dakota	97-04	Orange/Black	Blue	Driver Side Kick Panel (*Note 5)
Dodge	Dakota	05+	Lt .Green/Blue	Purple/Black	Driver Side Kick Panel Or Passenger Side Kick Panel (*Note 5)
Dodge	Ram 1500	94-03	Tan/Pink	Blue	Driver Side Kick Panel (*Note 5)
Dodge	Ram 1500/2500 3500	04-08	Brown/Orange or Tan/Green	Lime Green	Driver Side Kick Panel (*Note 5)
Dodge	Ram 1500/2500 3500	09+	Orange/Gray	Lime Green	Driver Side Kick Panel (*Note 5)
Dodge	Ram 2500 / 3500	94-03	Orange/Black	Pink/Violet	Driver Side Kick Panel (*Note 5)
Honda	Ridgeline	06+	Yellow/black	Yellow/green	Driver's Side Kick Panel(*Note 6)
Mazda	B-Series	99+	Pink/Black	Pink/Orange	Passenger Side Kick Panel (*Note 5)
Nissan	Titan	04+	Brown or Green/Yellow	Green/Red or Purple	Driver Side Kick Panel (*Note 5)
Nissan	Frontier	95-04	Brown	Green/Red	Driver Side Kick Panel (*Note 5)
Nissan	Frontier	05+	Purple	Green	Driver Side Kick Panel (*Note 5)
Toyota	Tacoma/Regular cab Access cab	98+	Blue	Blue/White	Driver Side Kick Panel(*Note 4)
Toyota	Tacoma/Double cab	98-06	Blue/Pink	Blue	Driver Side Kick Panel(*Note4)
Toyota	Tacoma/Double cab	07+	Blue/Black	Blue/Red	Driver Side Kick Panel(*Note 7)
Toyota	Tundra	99-03	Pink/Black	Red/Orange	Driver Side Kick Panel (*Note 5)
Toyota	Tundra	04+	Pink/Black or Blue/White	Red/Orange or Black/Yellow	Driver Side Kick Panel(*Note 3)
Toyota	Tundra/Crew Max Double Cab	07+	White	Blue	Diver Side Kick Panel –Top Blue Plug (*Note 5)
Toyota	Tundra/Double cab	04+	Blue/Red	Blue/Black	Diver Side Kick Panel (*Note 5)

*See Notes following page

VEHICLE WIRING CHART

(All wire color information is for reference only and may vary by vehicle)
Please verify with a test light

Note 1:

If the wiring is connected in the driver's side kick panel, the Handle will lock/unlock with the driver's door. If you prefer the Handle to lock/unlock with the passenger door, on some models the wiring may be connected into the passenger side kick panel using the same color wiring. If the same colors can't be found, use a test light to find the passenger side colors.

Note 2:

On the CHEVY/GMC 03+ Two door or Extended Cab Models, it is necessary to remove the driver's side door panel and attach the lock and unlock wires directly to the wires of the door lock actuator inside the door.

Once the door panel is removed, you will need to remove the driver's side kick panel and fish the harness wires through the rubber boot that runs between the door and the cab of the truck and into the door. Use the supplied Wire Taps to attach to the specified wires directly under the truck's door lock switch and test the locks. If the truck locks operate opposite the lid lock, reverse the connectors between the Lid Harness and Actuator.

Note 3:

Some 04 Toyota Tundra models used blue/white instead of pink/black for the lock wire and black/yellow instead of red/orange for the unlock wire.

Note 4:

Make sure the key is out of the ignition when testing this model.

Note 5:

If you have trouble locating the lock and unlock wires, test all the wires that are inside the rubber boot that runs between the door and the cab of the truck. Once you locate them you can follow them to a location that makes tapping to the wires easier. This works on most models except 03+ G.M.

Note 6:

On the Honda Ridgeline the lock and unlock wires are located in the fuse panel down by the driver's side kick panel. The yellow/black(lock) and the yellow/green(unlock) wires are in the small green plug that is located at the bottom front side of the fuse box. A small hole may need to be drilled in the side of the bed rail near the top rear on the driver's side of the bed to access the rear tail light compartment to attach the brake light and power lock wiring.

Note 7:

On the 07+ Double Cab Tacoma the lock wire is located in the 10 pin plug, pin#9, Blue/Black wire. The unlock wire is located in the 12 pin plug, pin#10, Blue/Red wire, both plugs are hanging loose in the driver side kick panel.

DT Design inc.

Holland, Michigan

1-877-551-LOCK(5625)

For Technical Support, Monday–Friday, 8:00 am to 5:00 pm EST:

1-877-551-TECH (8324) or (616) 403-3017