



INSTALLATION INSTRUCTIONS:

1. LONG FLANGE IS TO THE REAR.
2. 3° SHIM UNDER THE FRONT (SHORT FLANGE).