


SETTINGS


❑ Making your own color adjustment

- 1 Select [Panel Color] on the <User Customize> screen. (Page 66)



2

- 3 Select the dimmer setting for the color (1), then adjust the color (2).




❑ Storing your own scene for the background image


While playing a video or picture, you can capture an image and use the captured image as a background.

- You cannot capture copyrighted content and images from iPod/iPhone.
- When using a JPEG file as the background, make sure that the resolution is 800 x 480 pixels.
- The color of the captured image may look different from that of the actual scene.

- 1 Play a video or picture.
- 2 Display the <User Customize> screen. (Page 66)
- 3 Display the image adjustment screen.



- 4 Adjust the image.



- [▲][▼][◀][▶] Moves the zooming frame.
- [Q] Magnifies the scene. (<OFF>, <Zoom 1> – <Zoom 3>)
- [▶][▶]* Starts/pauses play/back.
- [▶][▶]* Advances scenes frame-by-frame.

- 5 To cancel the capture, press [Cancel]. Capture the image displayed on the screen.



A confirmation message appears. Press [Yes] to store the newly captured image. (The existing image is replaced with the new one.)

- Press [No] to return to the previous screen.

* Not displayed when playing an external component connected to the iPod/iPod-IN input terminal.