

14. Tighten the U-bolt nuts in a cross pattern in 4 stages.


*Torque:*

Stage 1: 26 lb.ft (35 Nm)

Stage 2: 52 lb.ft (70 Nm)

Stage 3: 74 lb.ft (100 Nm)

Stage 4: 98 lb.ft (133 Nm)



15. Tighten the new rear shock absorber lower nut and bolt.

*Torque:* 66 lb.ft (90 Nm)